



**File Name:** brother hl-5140 laser printer manual.pdf

**Size:** 3812 KB

**Type:** PDF, ePub, eBook

**Category:** Book

**Uploaded:** 25 May 2019, 22:46 PM

**Rating:** 4.6/5 from 709 votes.

**Status:** AVAILABLE

Last checked: 17 Minutes ago!

**In order to read or download brother hl-5140 laser printer manual ebook, you need to create a FREE account.**

[\*\*Download Now!\*\*](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

### Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with brother hl-5140 laser printer manual . To get started finding brother hl-5140 laser printer manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



## Book Descriptions:

# brother hl-5140 laser printer manual

Home; Need Help Live Chat; Laser Printers 20 Manual Awnings Gfnn110edww manual lawn, Peploes voucher sample, Cwa core contract negotiations, Table of contents report studio cognos, Herwig lighting 540 form. Reload to refresh your session. Reload to refresh your session. Please upgrade your browser to improve your experience. The Brother HL5140 Monochrome LaserJet is actually a standard desktop laser printer. It offers an expandable paper capacity which consists of a 250sheet standard input tray and another optional 250sheet tray. This machine has a quoted print speed of 21ppm pages per minute for quick mono printing. Also, if you rely on user guide or manual, this machine has its all operation instruction included on the disc installer. Its supplies though, especially the DR510 laser drum unit, may cost more or less about the price of the machine itself. While its cartridge, either the TN540 black toner with 3500 page yield, or the TN570 toner cartridge will work with it. With this printer, you may expect a decent output quality when it comes to text printing. At 2400x600 dpi dots per inch resolution, it can provide real crisp and clear mono printouts. Shop with us for highquality Brother compatible toner cartridges and laser drum unit to lower your printers cost per page. Please check your inbox, and if you can't find it, check your spam folder to make sure it didnt end up there. Please also check your spam folder. Please use the Quick Setup Guide to set up the printer. You can find a printed copy in the box. Please read this User's Guide thoroughly before you use the printer. Keep the CDROM in a convenient place so you can use it quickly if you need to. Please visit our web site at where you can get answers to Frequently Asked Questions FAQs, Product Support and Techn ical Questions, and the latest Driver Upd ates and Utilities. Were committed to dealing with such abuse according to the laws in your country of residence. <http://www.monclair.com.br/userfiles/cygnus-sa-1ab-manual.xml>

- **brother hl-5140 laser printer manual, brother hl 2140 laser printer manual, brother hl-5140 laser printer manual download, brother hl-5140 laser printer manual free, brother hl-5140 laser printer manual pdf, brother hl-5140 laser printer manual 2017, brother hl-5140 laser printer manual online, brother hl-5140 laser printer manual downloads, brother hl-5140 laser printer manual software, brother hl-5140 laser printer manual instructions, brother hl-5140 laser printer user manual.**

When you submit a report, well investigate it and take the appropriate action. Well get back to you only if we require additional details or have more information to share. Note that email addresses and full names are not considered private information. Please mention this; Therefore, avoid filling in personal details. The manual is 3 mb in size. If you have not received an email, then probably have entered the wrong email address or your mailbox is too full. In addition, it may be that your ISP may have a maximum size for emails to receive. Check your email Please enter your email address. Interface cable Front view Back view Positioning the printer Power supply Environment What kind of paper can I use. Please use the Quick Setup Guide to set up the printer. Please visit our web site at where you can get answers to Frequently Asked Questions FAQs, Product Support and Techn ical Questions, and the latest Driver Upd ates and Utilities. Remember these us eful ti ps when y ou use the p rinter. Cleanin g with vol atile liqui ds such as t hinner or benzene will damage the surf ace of the printer. Do not use cleaning material s that contain ammonia. They will damage the printer and th e toner cartridge. After y ou have just used the print er, so me parts i nside the printer will b e extr emely hot. When you open the front or back cover of the prin ter, never touch the sh aded parts shown in the illust rations below. There are hig h voltage electr odes inside the printe r. Before you clean t he prin ter, clear a paper jam or replace parts, make sure you have turned off the power

switch and unplugged the printer from the AC power outlet. Do not handle the plug with wet hands it might give you an electrical shock. Epson is a registered trademark and FX80 and FX850 are trademarks of Seiko Epson Corporation. Hewlett Packard is a registered trademark and HP LaserJet 6P, 6L, 5P, 5L, 4, 4L 4P, III, I IIP, II, and IIP are trademarks of Hewlett-Packard Company. <http://tennis-samara.ru/img/cygnus-mr320-manual.xml>

IBM, IBM PC, and Proprinter are registered trademarks of International Business Machines Corporation. ENERGY STAR is a U.S. registered mark. All other terms and brand and product names mentioned in this User's Guide are registered trademarks of their respective companies. Compilation and Publication Notice Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product's descriptions and specifications. The contents of this manual and the specifications of this product are subject to change without notice. We recommend that you save and use the original packaging. The Printer should also be adequately insured with the carrier. When you unpack the printer, check to see that you have all of the following parts. 1 Printer 2 Drum unit and toner cartridge assembly 3 Quick Setup Guide 4 CDROM 5 AC power cord Components may differ from one country to another. About this printer The power cord may be slightly different than the one in the figure above, depending on which country the printer was bought in. 1 2 3 4 5 Power supply Use the printer within the recommended power range. If you cannot avoid using the printer with these appliances, we recommend that you use a voltage transformer or a high frequency noise filter. Use a voltage regulator if the power source is not stable. Type and size of paper The printer loads paper from the installed paper tray, manual feed tray or optional lower tray unit. The names for the paper trays in the printer driver and this Guide are as follows While looking at this page on the CDROM, you can jump to the page for each printing method by clicking L in the table. For the paper you want to use, see What kind of paper can I use. Media Type Plain Paper Paper Source Tray 1 PCL driver PS driver For HL5150D and HL5170DN Illustrations in this section are based on HL5150D and HL5170DN.

Figure 15 3 While pressing the blue paper guide release lever, slide the paper guides to fit the paper size. Check that the guides are firmly in the slots. Figure 16 Check that the paper is flat in the tray at all four corners. Figure 17 5 Put the paper tray firmly back in the printer. Figure 1 8 When you use preprinted paper, put the side that is going to be printed on blank side face down, with the top of the paper at the front of the tray. Pull up the output tray support flap to prevent paper from sliding off the facedown output tray. Figure 1 9 If you choose not to pull out the output tray support flap, we recommend that you remove printed pages immediately after they come out of the printer. Media Type Plain Paper Paper Source Manual PCL driver 2 Send the print data to the printer. The printer automatically turns on the Manual Feed mode when you put paper in the manual feed tray. A NO PAPER message is shown in the Status Monitor and indicated by the control panel LEDs until you put a sheet of paper in the manual feed tray. Figure 110 Toner Drum Paper Status Slide the paper guides to fit the paper size. Figure 1 11 4 Using both hands put paper in the manual feed tray until the front edge of the paper touches the paper feed roller. Hold the paper in this position until the printer automatically feeds the paper in for a short distance, and then let go of the paper. Figure 1 12 5 After the printed page comes out of the printer, put in the next sheet of paper as in Step 4 above. Media Type Plain Paper Paper Source MP Tray PCL driver PS driver The printer automatically turns on the MP Tray mode when you put paper in the multipurpose tray. Figure 1 13 3 Pull out the MP tray support flap. Figure 1 14 4 When putting paper in the MP tray, make sure it touches the back of the tray and remains under the maximum paper height guides on both sides of the tray.

<http://superbia.lgbt/flotaganis/1649566037>

Figure 1 15 Make sure that the paper is straight and in the proper position on the MP tray. If it is

not, the paper may not be fed properly, resulting in a skewed printout or a paper jam. MP tray support flap Figure 1 16 6 Send the print data to the printer. When you select the paper you want to use, see What kind of paper can I use. Media Type Thick paper or Thicker paper Paper Source Manual PCL driver 2 Open the faceup output tray. Figure 1 17 Slide the paper guides to fit the paper size. Figure 1 19 5 Using both hands put the paper in the manual feed tray until the front edge of the paper touches the paper feed roller. Figure 1 20 A NO PAPER status is shown by the control panel LEDs until you put a sheet of paper in the manual feed tray. Figure 118 Toner Drum Paper Status Repeat for each page that you want to print. 7 Close the faceup output tray. Caution Remove each sheet immediately after printing. Stacking the sheets may cause a paper jam or the paper to curl. Media Type Thick paper or Thicker paper Paper Source MP Tray PCL driver PS driver Figure 1 23 4 Pull out the MP tray support flap. Figure 1 24 MP tray support flap Figure 1 25 6 While pressing the paperguide release lever, slide the paper guide to fit the paper size. Figure 1 26 7 Send the print data to the printer. 8 Close the faceup output tray. Make sure that the paper is straight and in the proper position in the MP tray. If it is not, the paper may not be fed properly, resulting in a skewed printout or a paper jam. Stacking the sheets may cause a paper jam or the paper to curl. Figure 1 27 However, some envelopes will have feed and print quality problems because of the way they have been made. A suitable envelope should have edges with straight, wellcrease d folds and the leading edge should not be thicker than two pieces of paper. The envelope should lie flat and not be of baggy or flimsy construction.

<https://meltonschool.org/images/concord-4-series-security-systems-manual.pdf>

You should buy quality envelopes from a supplier who understands that you will be using the envelopes in a laser printer. You are responsible for the quality and performance of the envelopes you use. Media Type Envelopes Paper Source Manual PCL driver 2 Open the faceup output tray. Figure 1 29 The printer automatically turns on the Manual Feed mode when you put paper in the manual feed tray. Slide the paper guides to fit the envelope size. Figure 1 31 A NO PAPER status is shown by the control panel LEDs until you put a sheet of paper in the manual feed tray. Figure 130 Toner Drum Paper Status Hold the envelope in this position until the printer automatically feeds it in for a short distance, and then let go of the envelope. Figure 1 33 Envelopes that have been creased after they have been printed At the back of the printer, open the faceup output tray and push down the blue tabs at the left and right hand sides as shown in the figure below. When you have finished printing your envelopes, close the faceup output tray to reset the two blue tabs back to their original position. Figure 132 Media Type Envelopes Paper Source MP Tray PCL driver PS driver The printer automatically turns on the MP Tray mode when you put paper in the MP tray. Figure 1 35 4 Pull out the MP tray support flap. Figure 1 36 MP tray support flap Do not put more than 3 envelopes in the MP tray at any one time, or it may cause a jam. Figure 1 38 Envelopes that have been creased after they have been printed At the back of the printer, open the faceup output tray and push down the blue tabs at the left and right hand sides as shown in the figure below. Figure 137 Make sure that the envelopes are neatly stacked and in the proper position in the MP tray. If they are not, the envelopes may not be fed properly, resulting in a skewed printout or a jam. Figure 1 39 7 Send the print data to the printer.

<http://mervemobilya.com/images/concord-4340z-manual.pdf>

8 After you finish the print job, close the faceup output tray. Put a new DL size double flap envelope in the MP tray with the longest edge of the envelope in first, then print again. Figure 1 40 3 While pressing the blue paperguide release levers, slide the paper guides to fit the transparency size. Check that the guides are firmly in the slots. Figure 1 41 4 Put transparencies in the tray. Do not put more than 10 transparencies in the tray at any one time, or it may cause a jam. Figure 1 42 Figure 1 44 Caution Remove each transparency immediately. Pull out the support flap to prevent transparencies from sliding off the facedown output tray. Figure 143 Media Type Transparencies

Paper Source Manual PCL driver 2 Open the faceup output tray. Figure 1 45 Slide the paper guides to the transparency size. Figure 1 47 5 Using both hands put the transparency in the manual feed tray until its front edge touches the paper feed roller. Hold the transparency in this position until the printer automatically feeds it in for a short distance, and then let go of the transparency. Figure 1 48 A NO PAPER status is shown by the control panel LEDs until you put a transparency in the manual feed tray. Figure 146 Toner Drum Paper Status Repeat for each transparency that you want to print. 7 After you finish the print job, close the faceup output tray. Caution Remove each transparency immediately after printing. Media Type Transparencies Paper Source MP Tray PCL driver PS driver Figure 1 49 3 Send the print data to the printer. 4 Open the MP tray and lower it gently. Figure 1 51 A NO PAPER status is shown by the control panel LEDs until you put a transparency in the MP tray. Figure 150 Toner Drum Paper Status Figure 1 52 6 When putting transparencies in the MP tray, make sure they touch the back of the tray and remain under the maximum paper height guides on both sides of the tray.

Do not put more than 10 transparencies in the MP tray at any one time, or it may cause a jam. Figure 1 53 7 While pressing the paperguide release lever, slide the paper guide to fit the transparency size. Figure 1 54 Make sure that the transparencies are straight and in the proper position in the MP tray. If they are not, the transparencies may not be fed properly, resulting in a skewed printout or a jam. Caution Remove each transparency immediately after printing. Stacking the printed transparencies may cause a paper jam or the transparency to curl. Remove the paper and straighten it. Printing on both sides of the paper manual duplex printing Manual duplex printing from the paper tray 1 Choose the Manual Duplex printing mode you need from the Advanced tab, and from the Basic tab select the Paper Source to be Tray1. 2 The printer will automatically print all the even numbered pages on one side of the paper first. 3 Remove the printed even numbered pages from the output tray and put them back in the paper tray, placing the paper with the side to be printed on blank side face down. Follow the instructions on the computer screen. Figure 1 55 4 The printer will now automatically print all the odd numbered pages on the other side of the paper. The PS driver does not support manual duplex printing. If you select the Paper Source to be Auto Select in Step 1 using HL5150D or HL5170DN, please put the printed even numbered pages in the MP tray. When you put paper in the paper tray, first empty the tray then put the printed page in it, with the printed side face up. Do not add the printed pages to the top of the stack of unprinted paper. Follow the instructions on the computer screen. Repeat this step until you have printed all the even numbered pages. Figure 1 56 3 Remove the printed even numbered pages from the output tray and put them in the same order back into the manual feed tray.

[conservationenergy.com/wp-content/plugins/formcraft/file-upload/server/content/files/16273ac09306c2---british-army-field-manual-1914.pdf](http://conservationenergy.com/wp-content/plugins/formcraft/file-upload/server/content/files/16273ac09306c2---british-army-field-manual-1914.pdf)

Place the paper with the side that is going to be printed on the blank side face up. Follow the instructions on the computer screen. Figure 1 57 4 Repeat Step 3 until you have printed all the odd numbered pages on the other side of the paper. If you select the Paper Source to be Auto Select in Step 1, please put the printed even numbered pages in the paper tray. Follow the instructions on the computer screen. Repeat this step until you have printed all the even numbered pages. Figure 1 58 3 Remove the printed even numbered pages from the output tray and put them in the same order back into the MP tray. Place the paper with the side that is going to be printed on the blank side face up. Follow the instructions on the computer screen. Figure 1 59 4 Repeat Step 3 until you have printed all the odd numbered pages on the other side of the paper. If you print 10 pages on 5 sheets of paper, it will print page 2 then page 1 on the first sheet of paper. It will print page 4 then page 3 on the second sheet of paper. It will print page 6 then page 5 on the third sheet of paper, and so on. To print the second side, put the paper face up, with the leading

edge top of the paper at the front of the tray. If letterhead paper is used, this would be put in the paper tray with the heading face up, and at the front of the tray. To print the second page, put the heading face down and at the front of the tray. For Thicker paper that has curled once the first side has been printed on, and you cannot feed the paper for the second time from manual feed tray or MP tray to allow the other side of the paper to be printed on. At the back of the printer, open the faceup output tray and push down the blue tabs on the left and right hand sides as shown in the figure below. When you have finished printing, close the face up output tray to reset the two blue tabs back to their original position.

Figure 160 Figure 161 This section is for HL5150D and HL5170DN. Letter or Legal size A4 size  
In the Advanced tab select Duplex Printing mode, check Duplex, and make sure that Use Duplex tray has been selected. Select Duplex Type and set Binding Offset if you need, and then click the OK button. The printer will print on both sides of the paper automatically. PCL driver PS driver  
Typically, this format is a printer command language or page description language. The printer drivers for the following operating systems are on the CDROM that we have supplied. Basic tab 1  
Select the Paper Size, Multiple Page, Orientation and so on. 2 Select the Paper Source and so on. The screens on your PC will vary depending on your Operating System. If you print with this setting, the print speed may be slower depending on the print data. To make the Booklet, fold the printed pages down the middle. When using the booklet printing function, please note that the paper size, orientation, source and other settings must remain unchanged for the whole document. Watermark You can place a watermarked logo or text into your documents. When you use a bitmap file as a watermark, you can change the size of the watermark and place it anywhere you like on the page. When you use text as a watermark, you can change the font, darkness and angle settings. To reprint press and hold down the Go button until all four LEDs are lit and then release the Go button. Quick Print Setup You can turn the Quick Print Setup function ON or OFF. A small selection window appears on your computer. Sleep mode acts as though the printer was turned off. The default timeout is 5 minutes. When Intelligent Sleep Mode is selected, it is automatically adjusted to the most suitable timeout setting depending on the frequency of your printer use. While the printer is in sleep mode, all the LEDs are off, but the printer can still receive data from the computer.

Receiving a print file or document automatically wakes up the printer to start printing. Pressing one of the buttons will also wake up the printer. Sleep mode can be turned off. To turn sleep mode off, go to the Advanced tab, select Device Options and then select Sleep Time. Double click the word Sleep Time in the Sleep Time screen, this will allow the Sleep Time Off function to appear, click Sleep Time Off to stop the printer going into sleep mode. The Sleep Time Off function can be hidden by double clicking the word Sleep Time in the Sleep Time screen again. We recommend that you keep Sleep mode on for power saving. Status Monitor This reports the printer status any errors that may happen with the printer when printing. The default setting for the Status Monitor is off. If you would like to turn the status monitor on, go to the Advanced tab, select Device options and then select Status monitor. Macro For HL 5140, HL5150D and HL5170DN You can save a page of a document as a macro to the printer memory. Moreover, you can execute the saved macro in other words, you can use the saved macro as an overlay on any document. This will save time and increase printing speed for often used information such as forms, company logos, letter head formats or invoices. If you want to prevent other people from printing your data using the Reprint function, clear the Use Reprint check box in the job spooling settings. The page protection feature allows the printer to create the full page image to be printed in memory before physically moving the paper through the printer. When the image is very complicated and the printer has to wait to process the image before printing, use this function. Time Specifies the format of the time. Density adjustment Increase or decrease the print density. Tray settings will match the installed options. 2 Paper Source Setting This feature recognizes the paper size in each paper tray.



3 Auto detection of printer options For HL5140, HL5150D and HL5170DN The Auto Detect function finds the currently installed devices and shows the available settings in the printer driver. When you click the Auto Detect button, options that are installed on the printer will be listed. You can manually add or remove options. Auto Detect function may not be available under certain printer conditions. 1 2 3 This section is for HL5150D and HL5170DN. The screens on your PC will vary depending on your Operating System. Sleep mode acts as though the printer was turned off. When Intelligent Sleep Mode is selected, it is automatically adjusted to the most suitable timeout setting depending on the frequency of your printer use. While the printer is in sleep mode, the LED is off, but the printer can still receive data from the computer. Receiving a print file or document automatically wakes up the printer to start printing. Pressing the GO button will also wake up the printer. We recommend that you keep Sleep mode on to save power. **Border** If you want to add a border, use this function. **Print on Both Sides** When you want to print on both sides of the paper, use this function. **Sleep Time** When the printer does not receive data for a certain period of time timeout, it enters sleep mode. We recommend that you keep Sleep mode on to save power. The administrator should set up the IP address, Gateway and Subnet with BRAdmin Professional before using this software. If the administrator then installs the printer driver and port driver using this software, the administrator can save the file to the file server or send the file by Email to users. Then, each user just clicks that file to have the printer driver, port driver, IP address, and so on, automatically copied to their PC. This section is for HL5170DN. When the printer receives data from the computer, it automatically chooses the emulation mode.

This feature has been set at the factory to ON. The printer can choose from the following combinations This section is for HL5150D and HL5170DN. Setting 1 default Setting 2 HP LaserJet HP LaserJet BRScript 3 BRScript 3 EPSON FX850 IBM ProPrinter XL Figure 31 The LED indications shown in the table below are used in the illustrations in this chapter. Control panel LED is off or or LED is on or or LED is blinking When the power switch is off or the printer is in Sleep mode, all the LEDs are off. Figure 33 Warming up The printer is warming up. Figure 34 Ready to print The printer is ready to print. Figure 35 Receiving data The printer is either receiving data from the computer, processing data in memory or printing the data. **Toner Drum Paper Status** Toner Drum Paper Status Toner Drum Paper Status Toner Drum Paper Status If the Status LED is on for a long time and not having printed, press the Go button to print the remaining data. Figure 37 Toner low Indicates that the toner cartridge is nearly empty. Purchase a new toner cartridge and have it ready for when Toner Empty is indicated. The Toner LED alternates turning on for 2 seconds and off for 3 seconds. Figure 38 Toner empty Replace the toner cartridge with a new one. See Replacing the toner cartridge on page 53. Figure 39 Drum unit near end of life The drum unit is near the end of its life. We recommend that you obtain a new drum unit to replace the current one. See Replacing the drum unit on page 59. The Drum LED alternates turning on for 2 seconds and off for 3 seconds. **LED Printer status** Toner Drum Paper Status Toner Drum Paper Status Toner Drum Paper Status Toner Drum Paper Status No paper Put paper in the printer. See Printing on plain paper in Chapter 1. Then press the Go button. **Misfeed** Put the paper back in properly, and then press the Go button. The printer will start printing again.

**Duplex Size Error** For HL5150D and HL5170DN Press the Go button. Specify the printable paper size. The paper size you can use for Duplex printing is A4, Letter or Legal. **No Duplex Tray** For HL5150D and HL5170DN Install the Duplex tray into the printer. **Duplex Lever Error** For HL5150D and HL5170DN Move the Duplex lever to the correct position. Figure 311 **Front Cover** Open Close the front cover of the printer. **Jam Clear Cover** Open Close the jam clear cover of the printer. See page 69. **Face up Open** For HL5150D and HL5170DN When you use the duplex printing function Close the face up output tray of the printer. **LED Printer status** Toner Drum Paper Status Toner Drum Paper Status Figure 312 If you see the service call indication above, follow the steps below 1 Take out the DIMM Dual Inline Memory Module from your printer, if you h

ave a DIMM installed. 2 Turn off the power switch, wait a few seconds, and then turn it back on and try to print again. If you cannot clear the error and see the same service call indication after turning the printer back on, call your dealer or a Brother authorized service representative. When you press the Go and the Job Cancel buttons together, the LEDs will light up with one of the combinations shown in Table 1. See Table 1 LED indications while pressing Go and Job Cancel on page 36 to identify the error. For example, the LED indication below shows a fixing unit failure. Figure 3 13 Toner Drum Paper Status Toner Drum Paper Status If the error occurs again, consult your dealer or Brother authorized service representative. Wake up If the printer is in Sleep mode, press the Go or Job Cancel button to wake the printer up and go to the Ready state. Form feed If the yellow Status LED is on, press the Go button. The printer will print any data that is left in the printer memory.

Error recovery If there is an error, the printer will recover automatically from some errors. If an error is not automatically cleared, press the Go button to clear the error, and then continue to use the printer. Reprint If you want to reprint a document that has just been printed, you can do this by pressing and holding down the Go button until all four LEDs are lit and then release the Go button. Using control panel button 1 Turn off the printer. 2 Make sure that the front cover is closed and the power cord is plugged in. 3 Hold down the Go button as you turn on the power switch. All the LEDs light up and then go off again. Keep the Go button pressed down until the Toner LED comes on. When the Toner LED comes on, release the Go button. 4 Press the Go button again. The printer will print a test page. Using the control panel button 1 Make sure that the front cover is closed and the power cord is plugged in. 2 Turn on the printer and wait until the printer is in the Ready state. 3 Press the Go button three times. The printer will print the current printer settings. Using the control panel button 1 Turn off the printer. 2 Make sure that the front cover is closed and the power cord is plugged in. 3 Hold down the Go button as you turn on the power switch. When the Toner LED comes on, release the Go button. 4 Press and hold the Go button again until the Drum LED comes on. 5 When the Drum LED comes on, release the Go button. The printer will print a list of the internal fonts. All the LEDs will light up. Keep the button pressed down until the Toner LED comes on. When the Toner LED comes on, release the Go button. 4 Hold down the Go button and keep it pressed down until the yellow Status LED comes on. When the Status LED comes on, release the Go button. 5 When all the LEDs light up again, the printer will start warning up. The print server has been reset to its default factory settings.

<https://www.becompta.be/emploi/bosch-wis24140gb-manual>